

# FleXinspect Guide to Container Inspection



**FleXinspect T** with all available options    **FleXinspect M** with all available options    **FleXinspect BC** with all available options    **FleXinspect B** with all available options    **FleXinspect C** with all available options

## Finish Defects

Bent or Crooked Finish					
Blisters					
Broken Finish					
Bulged Finish					
Checked Finish					
Chipped Finish					
Corkage Check					
Crizzled Finish					
Dirty or Rough Finish					
Lineover					
Neck Ring Seam					
Offset Finish					
Overpress/Wire Edge					
Saddle Finish					
Seeds					
Split Finish					
Stones					
Tear or Under Ring Check					
Unfilled or Dip Finish					

## Neck Defects

Bent Neck					
Choked Neck or Bore					
Danny Neck or Neck Tear					
Dirty Neck					
Long Neck					
Pinched Neck					
Stuck Glass Particles					

## Shoulder Defects

Shoulder Check					
Sunken Shoulders					
Thin Shoulder					

## Sidewall & Body Defects

Bird Cage (Bird Swing)					
Black Spots					
Blank and Blow Mold Seam					
Blisters					
Body Checks					
Body Dimension					
Brush Marks					
Bulged Sides					
Cold Mold					
Dirty Ware					
Drag Marks					
Freaks					
Hot or Panel Checks					
Lap Marks or Wrinkles					
Letter Checks					
Loading Marks					
Oil Marks					
Pressure Checks					
Seeds					
Sidewall Stress					
Spikes					
Stones					
Stuck Glass Particles					
Sunken Sides					
Swab Ware					
Thin Ware					
Washboard					

## Base Defects

Baffle Marks					
Base Check					
Base Leaner					
Base Spikes					
Base Stress					
Black Spots					
Blisters					
Dirty Ware					
Oil Marks					
Seeds					
Stones					
Stuck Glass Particles or Tramp Glass					
Swab Ware					
Swung Baffle					

## Other Defects

Broken Ware					
Horizontal Tear					
Out-Of-Shape Ware (Leaner)					
Over-Max Height					
Shear Marks					
Under-Min Height					
Uneven or Bad Distribution					
Vertical Tear					
Stuck Ware					